



## ***SYRUP FILLING MACHINE LSFM-A10***

# SYRUP FILLING MACHINE LSFM-A10

Syrup Filling Machine LSFM-A10 is a single head pneumatic syrup (liquid-cream consistency) filling machine. The cylinder body and piston are made of 316L stainless steel and lined with PTFE, conforming to GMP. It occupies less area, adopted with advanced pneumatic elements. It offers different filling range such as 5 to 100 ml, 10 to 200 ml, 50 to 500 ml for operation. Simple to operate, user-friendly design, delivers accurate filling results. As an ideal apparatus for filling fluid, it is useful in pharmaceuticals, daily chemicals, foodstuffs, cosmetics, pesticide and special trades.

## FEATURES

- Introduction of advanced filling machine technology
- Semi-automatic and piston type pasty liquid filling
- Adjustable filling volume and speed, with high accuracy
- Leakage-proof filling bulkhead, provision of lifting filling device
- Cost-effective design, delivers efficient results
- Filling process yields accurate quantities as defined
- Reduce human contact, minimized contamination

## APPLICATION

Syrup Filling Machine widely used in pharmaceutical, agriculture, food and beverage, and cosmetic product manufacturing, and packaging industry for syrup, pesticide, shampoo and other cosmetic product, food liquid and creams, solutions filling in bottle and other containers.

## SPECIFICATION

Model no.	LSFM-A10
Material Stainless	316 L Stainless Steel
Automatic Grade	Semi-Automatic
Power Source	Pneumatic
Filling Head	Single Head or Double Head or Customized
Air Pressure	0.4MPa
Filling Speed	≤ 3000pcs/hour
Filling Accuracy	≤ ± 1 %
Filling Range	5 to 100 ml, 10 to 200 ml, 50 to 500 ml
Dimension	1150 × 510 × 450 mm
Weight	70 kg